

How to Order Ti-Matic® Blind Bolts

EXAMPLE: UB100-MV06-06

U (B100) - (MV) (06) - (06) - ()

